



Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------



LEGO Power Functions RC

Version 1.20



Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

Introduction

The purpose of this document is to describe the RC protocol supported by the LEGO Power Functions RC Receiver.



Attention!

Please feel free to use any information from this document for personal, non-commercial use only, provided you keep intact copyright, trademark and other proprietary rights of the The LEGO Group – have fun.

The LEGO Group 02/2010



Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

Table of content

- Introduction.....2**
- Table of content.....3**
- LEGO Power Functions RC.....4**
 - LEGO Power Functions RC Receiver4
 - Application Schematics4
 - Description5
 - LEGO Power Functions RC Protocol.....6
 - Extended mode7
 - Combo direct mode8
 - Single output mode.....9
 - Combo PWM mode.....10
 - LEGO Power Functions RC Encoding11
 - Transmitting Messages12
 - LEGO Power Functions RC Decoding.....13
 - Receiving Messages13




Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------


LEGO Power Functions RC

LEGO Power Functions RC Receiver

The receiver has input for IR data and channel switch and output for two LPF plugs and one LED.



Application Schematics





Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

Description

This receiver firmware is capable of executing all commands in the “LPF RC Protocol” – acting in a variety of RC modes. Each mode implements a certain type of RC functionality.

When applying supply voltage the LED will give a short blink and then light up - the receiver is now ready. If a legal valid command of the right channel is received the LED will shortly turn off and indicate that the command is executed. The effect you will see is the LED blinking when messages are received.

The outputs of the RC Receiver are generic Power Functions outputs – in the following we will use motors as examples to describe the functionality of the control.

Depending on command the four output port pins will turn into two motor controls or individually controlled outputs. The motor outputs will either be forward, float, brake, backward – ON/OFF or PWM controlled. Some commands are timed out after 1.2 second when not receiving IR others are not. Default behavior is floating outputs.

The receiver does not power down and can only be turned off by removing its supply voltage.



Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

LEGO Power Functions RC Protocol

The payload is: 1 toggle bit, 1 escape bit, 2 bits for channel switch, 1 bit for address, 3 bits for mode and 4 bits for various data depending on mode.

The address bit is intended for enabling an extra set of 4 channels for future use. The current PF RC Receiver expects by default the address bit to be 0.

A message consists of: A special length synchronisation start bit, payload and “Longitudinal Redundancy Check” to validate the entire message before executing the command and at last a stop bit to terminate the message.

Binary representation:

	Nibble 1				Nibble 2				Nibble 3								
start	T	E	C	C	a	M	M	M	D	D	D	D	L	L	L	L	stop
Start	Toggle	Escape	Channel		Address	Mode			Data				LRC				Stop

Start	start	Special synchronisation start bit (see description under “Encoding”)	
Toggle	T	0-1	Toggling for every new command
Escape	E	0	Use “Mode” to select the modes listed below
		1	Combo PWM mode
Channel	CC	0-3	Channel switch 1 - 4
Address	a	0	Default address space (from power up)
		1	Extra address space
Mode	MMM	000	Extended mode
		001	Combo direct mode
		01x	Reserved
		1xx	Single output mode
Data	DDDD	0-15	Data: different meaning depending on “Mode”
LRC	LLLL	xxxx	= 0xF xor Nibble 1 xor Nibble 2 xor Nibble 3
Stop	stop	Same as Start	



Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

Extended mode

This mode is able to control:

Brake, increment and decrement PWM in 7 steps on Output A and toggle Forward/Float on Output B. Toggle bit is verified on receiver. No timeout for lost IR.

From power up the address bit is always expected to be 0 (default address space). If the “Toggle Address bit” command is received (with a = 0) the extra address space is used and commands are from now expected to have the address bit set to 1. A new “Toggle Address bit” command (now with a = 1) will toggle back to default address space.

The “Align toggle bit” command has no action and is used to make sure the next command send is in sync.

Binary representation:

<i>start</i>	Nibble 1				Nibble 2				Nibble 3				<i>stop</i>				
	<i>T</i>	<i>0</i>	<i>C</i>	<i>C</i>	<i>a</i>	<i>0</i>	<i>0</i>	<i>0</i>	<i>F</i>	<i>F</i>	<i>F</i>	<i>F</i>		<i>L</i>	<i>L</i>	<i>L</i>	<i>L</i>
Start	Toggle	Escape	Channel		Address	Mode			Data				LRC				Stop

Function	<i>FFFF</i>	0000	Brake then float output A
		0001	Increment speed on output A
		0010	Decrement speed on output A
		0011	Not used
		0100	Toggle forward/float on output B
		0101	Not used
		0110	Toggle Address bit
		0111	Align toggle bit (get in sync)
		1000	Reserved



Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

Combo direct mode

This mode is able to control: Two outputs float/forward/backward/brake.

This is a combo command controlling the state of both output A and B at the same time.

Toggle bit is not verified on receiver.

This mode has timeout for lost IR.

Binary representation:

<i>start</i>	Nibble 1				Nibble 2				Nibble 3				<i>stop</i>				
	<i>T</i>	<i>0</i>	<i>C</i>	<i>C</i>	<i>a</i>	<i>0</i>	<i>0</i>	<i>I</i>	<i>B</i>	<i>B</i>	<i>A</i>	<i>A</i>		<i>L</i>	<i>L</i>	<i>L</i>	<i>L</i>
Start	Toggle	Escape	Channel		Address	Mode			Data				LRC				Stop

B output **BB** 00xx Float output B
 01xx Forward on output B
 10xx Backward on output B
 11xx Brake **then float** output B

A output **AA** xx00 Float output A
 xx01 Forward on output A
 xx10 Backward on output A
 xx11 Brake **then float** output A



Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

Single output mode

This mode is able to control: One output at a time with PWM or clear/set/toggle control pins.

Toggle bit is verified on receiver if increment/decrement/toggle command is received.

This mode has no timeout for lost IR on all commands except “full forward” and “full backward”.

Binary representation:

start	Nibble 1			Nibble 2				Nibble 3				stop					
	T	O	C	C	a	I	M	O	D	D	D		D	L	L	L	L
Start	Toggle	Escape	Channel	Address	Mode				Data				LRC				Stop

Mode	M	0	PWM
		1	Clear/Set/Toggle/Inc/Dec

Output	O	0	Output A
		1	Output B

Mode = PWM

Data	DDDD	0000	Float
		0001	PWM forward step 1
		0010	PWM forward step 2
		0011	PWM forward step 3
		0100	PWM forward step 4
		0101	PWM forward step 5
		0110	PWM forward step 6
		0111	PWM forward step 7
		1000	Brake then float
		1001	PWM backward step 7
		1010	PWM backward step 6
		1011	PWM backward step 5
		1100	PWM backward step 4
		1101	PWM backward step 3
		1110	PWM backward step 2
		1111	PWM backward step 1

Mode = Clear/Set/Toggle/Inc/Dec

Data	DDDD	0000	Toggle full forward (Stop → Fw, Fw → Stop, Bw → Fw)
		0001	Toggle direction
		0010	Increment numerical PWM
		0011	Decrement numerical PWM
		0100	Increment PWM
		0101	Decrement PWM
		0110	Full forward (timeout)
		0111	Full backward (timeout)
		1000	Toggle full forward/backward (default forward)
		1001	Clear C1 (negative logic – C1 high)
		1010	Set C1 (negative logic – C1 low)
		1011	Toggle C1
		1100	Clear C2 (negative logic – C2 high)
		1101	Set C2 (negative logic – C2 low)
		1110	Toggle C2
		1111	Toggle full backward (Stop → Bw, Bw → Stop, Fwd → Bw)



Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

Combo PWM mode

This mode is able to control: Two outputs with PWM in 7 steps forward and backward.
 This is a combo command controlling the state of both output A and B at the same time.
 Toggle bit is not verified on receiver.
 This mode has timeout for lost IR.

Binary representation:

<i>start</i>	Nibble 1				Nibble 2				Nibble 3				<i>stop</i>				
	<i>a</i>	<i>I</i>	<i>C</i>	<i>C</i>	<i>B</i>	<i>B</i>	<i>B</i>	<i>B</i>	<i>A</i>	<i>A</i>	<i>A</i>	<i>A</i>		<i>L</i>	<i>L</i>	<i>L</i>	<i>L</i>
Start	Address	Escape	Channel		Output B				Output A				LRC				Stop

Output B

- BBBB** 0000 Float
 0001 PWM forward step 1
 0010 PWM forward step 2
 0011 PWM forward step 3
 0100 PWM forward step 4
 0101 PWM forward step 5
 0110 PWM forward step 6
 0111 PWM forward step 7
 1000 Brake **then float**
 1001 PWM backward step 7
 1010 PWM backward step 6
 1011 PWM backward step 5
 1100 PWM backward step 4
 1101 PWM backward step 3
 1110 PWM backward step 2
 1111 PWM backward step 1

Output A

- AAAA** 0000 Float
 0001 PWM forward step 1
 0010 PWM forward step 2
 0011 PWM forward step 3
 0100 PWM forward step 4
 0101 PWM forward step 5
 0110 PWM forward step 6
 0111 PWM forward step 7
 1000 Brake **then float**
 1001 PWM backward step 7
 1010 PWM backward step 6
 1011 PWM backward step 5
 1100 PWM backward step 4
 1101 PWM backward step 3
 1110 PWM backward step 2
 1111 PWM backward step 1




Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

LEGO Power Functions RC Encoding

To ensure correct detection of IR messages six 38 kHz cycles are transmitted as mark. Low bit consists of 6 cycles of IR and 10 “cycles” of pause, high bit of 6 cycles IR and 21 “cycles” of pause and start bit of 6 cycles IR and 39 “cycles” of pause.


Graphically drawn:



The high pulse illustrates six 38 kHz cycles.

Low bit length = $16 \times 1/38K = 421 \text{ us}$
 High bit length = $27 \times 1/38K = 711 \text{ us}$
 Start bit length = $45 \times 1/38K = 1184 \text{ us}$
 Stop bit length = $45 \times 1/38K = 1184 \text{ us}$

This example shows start bit, 6 bits and stop bit (not really the actual protocol).





Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

Transmitting Messages

When a button is pressed or released on the transmitter the message is sent. Five exactly matching messages (if no other buttons are pressed or released) are sent accordingly in time intervals depending on the channel selected. This ensures that other transmitters are not interfering with all the messages.



When a button is held down and the protocol needs update to prevent timeout the message is send continuously with a time interval as between message 4 and 5. First after all buttons are released and this is transmitted the transmitter will shut down.

If t_m is the maximum message length (16ms) and Ch is the channel number, then

The delay before transmitting the first message is: $(4 - \text{Ch}) * t_m$

The time from start to start for the next 2 messages is: $5 * t_m$

The time from start to start for the following messages is: $(6 + 2 * \text{Ch}) * t_m$




Document title: LEGO Power Functions RC	Init: GMu	Date: 26.02.2010	Version: 1.20
---	---------------------	----------------------------	-------------------------

LEGO Power Functions RC Decoding

Decoding of message bits is done by measuring time from start of IR detection to next start of IR detection. Using only one, the active edge, stabilize the measured time nearly without influence of the automatic gain control in the IR receiver.

The example from above:



When the stop bits pause is reached the message is processed.

Receiving Messages

The receiving firmware looks for a start bit and when this is detected it samples 16 data bits, calculates and compares the LRC. If any of the sampled bits are too long the sampling is terminated immediately and a new start bit is searched for.

When a bit time is sampled (measured) its time is hold against some limits.

Low bit range	316 - 526 us
High bit range	526 - 947 us
Start/stop bit range	947 - 1579 us

Depending on the bit time a low or high bit is rotated into the receive buffer.